



REVISION HISTORY			
REV	DESCRIPTION	DATE	APPROVED
-	NRN 47858	11/23	SEE PDM



STEP 1:
TRIM CABLE TO DIMENSIONS SHOWN. BE CAREFUL NOT TO NICK CENTER CONDUCTOR.

STEP 2:
POINT CENTER CONDUCTOR.



STEP 3:
INSERT PREPARED CABLE INTO CONNECTOR ASSEMBLY, CENTER CONDUCTOR WILL ENTER A SOCKET CONTACT, AND SOLDER AS SHOWN.

MATERIAL:	N/A
FINISH:	N/A
SURFACE AREA:	N/A
PROPRIETARY	
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF SV MICROWAVE, INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF SV MICROWAVE, INC IS PROHIBITED.	

DIMENSIONS ARE IN INCHES TOLERANCES:	
FRACTIONAL:	$\pm 1/64$ ANGULAR: X° $\pm 1'0''$ X°X' $\pm 15''$
DECIMAL:	X $\pm .030$.XX $\pm .010$.XXX $\pm .005$
INTERPRET DIMENSIONS AND TOLERANCES PER ASME Y14.5M - 1994	
THIRD ANGLE PROJECTION	

UNLESS OTHERWISE SPECIFIED	
1) ALL DIMENSIONS ARE AFTER PLATING. 2) BREAK CORNERS & EDGES .005 R. MAX. 3) CHAM. 1ST & LAST THREADS. 4) SURFACE ROUGHNESS 63 / MIL-STD-10. 5) DIA.'S ON COMMON CENTERS TO BE CONCENTRIC WITHIN .005 T.I.R. 6) REMOVE ALL BURRS	
DRAWN:	BFB 11/06/23
CHECKED:	SEE PDM
APPROVED:	SEE PDM
E.M. SIMULATION:	N/A



TITLE:		CABLE ASSEMBLY INSTRUCTIONS	
SIZE	DWG. NO.	300-83-000	
B		SCALE: 12:1	SHEET 1 OF 1

8341-40001
USED ON: